

GUIDE 25 – SMARTFIX Installation Process Schematic.

PROCESS STEP 1
Secure frames to glazing panel. *Ensure brush gasket in each frame is on the same side of the panel for all frames.*

PROCESS STEP 2
Secure frames together using glazing frame brackets (with No.8 x 25 C/S screws) after frames secured in place around glazing panel

PROCESS STEP 4
When the glazing panel and frames are fully assembled fix Toggle-Clips in place with No. 6 x 25 Screw. Toggle-clip should fit snugly against the frames and be located symmetrically around each frame.

PROCESS STEP 3
Secure glazing panel within frames with **WEDGE GASKET**

